

## ML2i / ML3 USB Host Adapter

These instructions will help you to update the internal firmware of the USB Host Adapter



1. Download the firmware zip file (FxxxxxxX.zip). Please unzip this file on your hard drive. The unzipped file name is FxxxxxxX.bin (firmware)
2. Copy this file (FxxxxxxX.bin) to the USB memory stick in the directory/folder called "carrier". The file will otherwise not be recognized by the UHA.
3. Place the USB memory stick in the UHA and insert the UHA into the ML3 controller.
4. Switch **ON** the reefer machinery
5. Go to the menu option "PROG UHA" by using the arrow keys. Press "ENTER" and the display shows "XXXX XX", press "ENTER" again.
6. Display starts counting to 100 (approx 20 sec), after installation, the controller reboots itself and the UHA is updated. You can check this by pressing the "ALT MODE" key. Version number should be "XXXX-XX-XX".
7. Remove the file (FxxxxxxX.bin) from the USB memory stick, is no longer needed.

